

Practical: 2

AIM: To study various inner interfaces, components and units of a computer and prepare complete interface layout.

Procedure:




Figure 2.1: Motherboard

1. Mouse & keyboard**2. USB****3. Parallel port****4. CPU Chip****5. RAM slots****6. Floppy controller****7. IDE controller****8. PCI slot****9. ISA slot****10. CMOS Battery****11. AGP slot****12. CPU slot****13. Power supply plug in****1. Mouse & keyboard:**

- Keyboard Connectors are basically two types.
- All PCs have a Keyboard port connected directly to the motherboard.
- The oldest, but still quite common type, is a special DIN, and most PCs until recently retained this style connector.
- The AT-style keyboard connector is quickly disappearing, being replaced by the smaller mini DIN PS/2-style keyboard connector.



Figure 2.2:Keyboard and Mouse

2. USB (Universal serial bus):

- USB is the General-purpose connection for PCs.

- You can find USB versions of many different devices, such as mice, keyboards, scanners, cameras, and even printers.
- A USB connector's distinctive rectangular shape makes it easily recognizable.



Figure 2.3: USB

3. Parallel port:

- Most printers use a special connector called a parallel port.
- Parallel ports carry data on more than one wire, as opposed to the serial port, which uses only one wire. Parallel ports use a 25-pin female DB connector.
- Parallel ports are directly supported by the motherboard through a direct connection or through a dangle.



Figure 2.4: Parallel Port

4. CPU Chip :

- The central processing unit, also called the microprocessor performs all the calculations that take place inside a pc. CPUs come in Variety of shapes and sizes.
- Modern CPUs generate a lot of heat and thus require a cooling fan or heat sink.
- The cooling device (such as a cooling fan) is removable, although some CPU manufacturers sell the CPU with a fan permanently attached.



Figure 2.5 : CPU Chip

5. RAM slots:

- Random-Access Memory (RAM) stores programs and data currently being used by the CPU.

- RAM is measured in units called bytes. RAM has been packaged in many different ways.
- The most current package is called a 168-pin DIMM (Dual Inline Memory module).




Figure 2.6 : RAM Slots

6. Floppy controller:

- The floppy drive connects to the computer via a 34-pin ribbon cable, which in turn connects to the motherboard.
- A floppy controller is one that is used to control the floppy drive.



Figure 2.7: Floppy Controller

7. IDE controller:

- Industry standards define two common types of hard drives: EIDE and SCSI.
- Majority of the PCs use EIDE drives. SCSI drives show up in high end PCs such as network servers or graphical workstations.
- The EIDE drive connects to the hard drive via a 2-inch-wide, 40-pin ribbon cable, which in turn connects to the motherboard.
- The IDE controller is responsible for controlling the hard drive.




Figure 2.8: IDE Controller

8. PCI slot:

- Intel introduced the Peripheral component interconnect bus protocol.
- The PCI bus is used to connect I/O devices (such as NIC or RAID controllers) to the main logic of the computer.
- The PCI bus has replaced the ISA bus.



Figure 2.9: PCI Slot

9. ISA slot:

- (Industry Standard Architecture) It is the standard architecture of the Expansion bus. Motherboard may contain some slots to connect ISA compatible cards.



Figure 2.10 : ISA Slot

10. CMOS Battery:

- To provide CMOS with the power when the computer is turned off all motherboards come with a battery.

- These batteries mount on the motherboard in one of three ways: the obsolete external battery, the most common onboard battery, and built-in battery.



Figure 2.11: CMOS Battery

11. AGP Slot:

- If you have a modern motherboard, you will almost certainly notice a single connector that looks like a PCI slot, but is slightly shorter and usually brown.
- You also probably have a video card inserted into this slot. This is an Advanced Graphics Port (AGP) slot.



Figure 2.12: AGP Slot

12. CPU slot:

- To install the CPU, just slide it straight down into the slot.
- Special notches in the slot make it impossible to install them incorrectly.
- So remember if it does not go easily, it is probably not correct. Be sure to plug in the CPU fan's power.




Figure 2.13: CPU Slot

13. Power supply plug in:

- The Power supply, as its name implies, provides the necessary electrical power to make the pc operate. the power supply takes standard 110-V AC power and converts it into 12-Volt, 5-Volt, and 3.3-Volt DC power.



Figure 2.14: Power Supply plug in